

# Omega National

P R O D U C T S

## Super Susan Installation

### Installation Instructions

**Step 1:** Make sure the Detent in the steel bearing is engaged.



**Step 2:** Place the SSusan in the cabinet in the desired location



**Step 3:** Turn the SSusan to expose the corner of the base plate, making sure to apply enough downward pressure to disengage the detent while not allowing the base plate to turn.



**Step 4:** Screw the SSusan down to the shelf (pre-drilling may be necessary) through the corner of the base plate. Repeat for the other 3 Corners.

